




































| Original | Replacement | Original | Replacement |
|-------------|---|------------|---|
| PWR On/Off |  Power | OK Enter |  Ok |
| Mute |  Mute | Menu Right |  Right |
| Epg |  +  Shift + Guide | Exit |  Exit |
| Opt? |  Options | Menu Down |  Down |
| App |  Media | Back |  Back |
| Info |  +  Shift + Info | Volume+ |  Vol + |
| Subt.List |  Subt | Audio |  Dual |
| Sleep Timer |  Sleep | CH/Page+ |  Ch + |
| TV |  TV/R | Volume- |  Vol - |
| Video |  D. Menu | CH/Page- |  Ch - |
| Text |  Text | 1. ? |  1 |
| Zoom |  Eject | 2abc |  2 |
| TV/SAT |  AV | 3def |  3 |
| Menu |  Menu | 4ghi |  4 |
| Menu Up |  Up | 5jkl |  5 |
| Display |  Info | 6mno |  6 |
| Menu Left |  Left | 7pqrm |  7 |



| Original | Replacement | Original | Replacement |
|---------------|--|----------|--|
| 8tuv |  8 | |  Shift + Ch - |
| 9wxyz |  9 | | |
| Guide Pilote |  Guide | | |
| 0/10 |  0 | | |
| FAV Pref. |  Pre Ch | | |
| Red |  Red | | |
| Green |  Green | | |
| Dec/Pause |  Pause | | |
| Freeze |  Stop | | |
| East |  >> | | |
| Yellow |  Yellow | | |
| Lang./Rewind |  << | | |
| H/V Play |  Play | | |
| LNB F.Forward |  >> | | |
| Blue |  Blue | | |
| |  Shift + Mute | | |
| |  Shift + Ch + | | |

