



| Original  | Replacement  | Original  | Replacement            |
|---|--------------|---|------------------------|
|      | Power        |      | Power                  |
|      | Mute         |      | Mute / Dimmer          |
|      | 1            |      | 1                      |
|      | 2            |      | 2                      |
|      | 3            |      | 3                      |
|      | 4            |      | 4                      |
|      | 5            |      | 5                      |
|      | 6            |      | 6                      |
|      | 7            |      | 7                      |
|      | 8            |      | 8                      |
|     | 9            |     | 9                      |
|    | TV / Radio   |    | TV/Radio /             |
|    | 0            |    | 0                      |
|    | ←PR          |    | Back / Return          |
|    | EPG          |    | Guide / EPG / -/--     |
|    | Up / PR+     |    | CH+ / Page+            |
|    | Up / PR+     |    | Up                     |
|    | Menu         |    | Menu / Home            |
|    | Left / Vol-  |    | Left                   |
|    | Left / Vol-  |    | Vol-                   |
|    | OK / List    |    | OK                     |
|    | OK / List    |    | Smart / List           |
|    | Right / Vol+ |    | Vol+                   |
|    | Right / Vol+ |    | Right                  |
|    | FAV          |    | Fav / Marker / PC      |
|    | Down / PR-   |    | CH- / Page-            |
|    | Down / PR-   |    | Down                   |
|   | Exit         |   | Exit / Cancel / Clear  |
|  | Red / Find   |  | Red / Netflix / Search |
|  | ↑            |  | >>  / Preset+          |
|  | ↑            |  | >> / Tune+             |
|  | Green / Zoom |  | Zoom / Size            |
|  | Green / Zoom |  | Green / APP / Repeat   |
|  | ↓            |  | << / Tune-             |



