









































































Original	Replacement	Original	Replacement
 Power Tv	 Power	 Vol-	 Vol -
 Source	 AV	 Prog+	 Ch +
 1	 1	 Prog-	 Ch -
 2	 2	 Red	 Red
 3	 3	 Green	 Green
 4	 4	 Yellow	 Yellow
 5	 5	 Blue	 Blue
 6	 6	 OK	 Ok
 7	 7	 Up	 Up
 8	 8	 Down	 Down
 9	 9	 Right	 Right
 0	 0	 Left	 Left
 [≡]	 Text	 Guide	 Guide
 [...]	 Subt	 Options	 Options
 Mute	 Mute	 Return/Back	 Back
 Audio	 Dual	 [i+]	 Info
 Vol+	 Vol +	 Home	 Smart









































































Original	Replacement
 FAV	 Pre Ch
 Wide	 Format
 Sync Menu	 Menu
 Stop	 Stop
 Play	 Play
 >>	 >>
 <<	 <<
 Theatre	 TV/R
 >>	 >>
  <<	  <<
 Digital/Analog	 Sleep
 Exit	 Exit
 ?/i-Manual	 Shift + D. Menu
 Scene	 3D
 Top Menu	 Shift + Menu
 Menu	 D. Menu
 Internet Widgets	 Media


Original	Replacement
 Internet Video	 Eject










































































Original		Replacement		Original		Replacement	
	Power DVD		Power		Audio		Dual
	1		1		OK		Ok
	2		2		Up		Up
	3		3		Down		Down
	4		4		Right		Right
	5		5		Left		Left
	6		6		Return/Back		Back
	7		7		Home		Smart
	8		8		[i+]		Info
	9		9		Play		Play
	0		0		>>		>>
	[...]		Subt		<<		<<
	Mute		Mute		Stop		Stop
	Vol+		Vol +		>>		>>
	Vol-		Vol -		I<<		I<<
	Prog+		Ch +		Top Menu		Shift + Menu
	Prog-		Ch -		Menu		Menu









































































Original		Replacement		Original		Replacement	
	Power BD		Power		OK		Ok
	1		1		Up		Up
	2		2		Down		Down
	3		3		Right		Right
	4		4		Left		Left
	5		5		[i+]		Info
	6		6		Return/Back		Back
	7		7		Options		Options
	8		8		Home		Smart
	9		9		<<		<<
	0		0		>>		>>
	[≡]		Text		Play		Play
	[...]		Subt		I<<		I<<
	Audio		Dual		>>I		>>I
	Vol+		Vol +		Stop		Stop
	Vol-		Vol -		Menu		Menu
	Mute		Mute		Top Menu		Shift + Menu





Original		Replacement		Original		Replacement	
	Power AMP		Power		Audio		Dual
	Source		AV		OK		Ok
	1		1		Up		Up
	2		2		Down		Down
	3		3		Right		Right
	4		4		Left		Left
	5		5		[i+]		Info
	6		6		Return/Back		Back
	7		7		Home		Smart
	8		8		Play		Play
	9		9		>>		>>
	0		0		<<		<<
	[≡]		Text		Stop		Stop
	[...]		Subt		>>		>>
	Vol+		Vol +		I<<		I<<
	Vol-		Vol -		Top Menu		Shift + Menu
	Mute		Mute		Menu		Menu

