











































| Original   | Replacement  |
|--|--|
|  Power          |  Power          |
|  Theatre        |  Smart          |
|  One-Touch Play |  Shift + Play  |
|  Eject          |  Eject          |
|  Sleep          |  Sleep          |
|  Display        |  Shift + Info  |
|  Function       |  Options        |
|  Tone           |  3D             |
|  Night          |  Shift + Sleep |
|  Dimmer        |  Shift + Mute |
|  Repeat       |  Text         |
|  1            |  1            |
|  2            |  2            |
|  3            |  3            |
|  4            |  4            |
|  5            |  5            |
|  6            |  6            |

| Original   | Replacement  |
|--|--|
|  7              |  7              |
|  8              |  8              |
|  9              |  9              |
|  0              |  0              |
|  Clear          |  Exit           |
|  Enter          |  Pre Ch         |
|  Picture Navi   |  List           |
|  Audio          |  Dual           |
|  Subtitle       |  Subt           |
|  D.Tuning      |  Media         |
|  Angle        |  Format       |
|  DVD Top Menu |  Shift + Menu |
|  DVD Menu     |  D. Menu      |
|  Up           |  Up           |
|  Left         |  Left         |
|  OK           |  Ok           |
|  Right        |  Right        |







































































| Original  | Replacement   |
|---|---|
|  Down              |  Down  |
|  Return            |  Back  |
|  System Menu       |  Menu  |
|  [ + ] Display     |  Info  |
|  I<< / Preset-     |  I<<   |
|  Replay            |  Shift +<br> Left  |
|  Advance           |  Shift +<br> Right |
|  >>I / Preset+     |  >>I   |
|  << / <I / Tuning- |  <<  |
|  Play              |  Play  |
|  >> / I> / Tuning+ |  >>  |
|  Pause            |  Pause  |
|  Stop            |  Stop  |
|  TV              |  TV/R  |
|  Muting          |  Mute  |
|  Volume+         |  Vol +   |
|  Volume-         |  Vol -   |

| Original  | Replacement  |
|---|--|
|  Sound Mode+ |  Ch + |
|  Sound Mode- |  Ch - |
|   |  |
|   |  |
|   |  |
|   |  |
|   |  |
|   |  |
|   |  |
|   |  |
|   |  |
|   |  |
|   |  |
|   |  |
|   |  |
|   |  |
|   |  |
|   |  |
|   |  |





|   | Original | Replacement   |  | Original  | Replacement     |
|---|----------|---|--|---|-----------------|
|    | Power    |    |  |  | Source          |
|    | [i+]     |    |  |  | Tools / Options |
|    | Analog   |    |  |  | Home / Menu     |
|    | Digital  |    |  |  | Muting          |
|    | 1        |    |  |  | Volume+         |
|    | 2        |    |  |  | Volume-         |
|    | 3        |    |  |  | Prog+           |
|    | 4        |    |  |  | Prog-           |
|    | 5        |    |  |   |                 |
|    | 6        |    |  |   |                 |
|   | 7        |   |  |   |                 |
|  | 8        |  |  |   |                 |
|  | 9        |  |  |   |                 |
|  | 0        |  |  |   |                 |
|  | Text     |  |  |   |                 |
|  | -/--     |  |  |   |                 |
|  | Guide    |  |  |   |                 |

|   | Original        | Replacement   |  | Original  | Replacement     |
|---|-----------------|---|--|---|-----------------|
|  | Source          |  |  |  | Source          |
|  | Tools / Options |  |  |  | Tools / Options |
|  | Home / Menu     |  |  |  | Home / Menu     |
|  | Muting          |  |  |  | Muting          |
|  | Volume+         |  |  |  | Volume+         |
|  | Volume-         |  |  |  | Volume-         |
|  | Prog+           |  |  |  | Prog+           |
|  | Prog-           |  |  |  | Prog-           |
|   |                 |   |  |   |                 |
|   |                 |   |  |   |                 |
|   |                 |   |  |   |                 |
|   |                 |   |  |   |                 |
|   |                 |   |  |   |                 |
|   |                 |   |  |   |                 |
|   |                 |   |  |   |                 |
|   |                 |   |  |   |                 |
|   |                 |   |  |   |                 |
|   |                 |   |  |   |                 |

