






Original	Replacement	Original	Replacement
	Power		Power
	Input+		Ch +
	Input-		Ch -
	Clear Audio+		Exit
	Display		Info
	Voice		Sleep
	Night		Media
	Bluetooth/Pairing		TV/R
	Music Service		Subt
	Dimmer		Pre Ch
	Options		Options
	Back		Back
	Home		Smart
	Mute		Mute
	Vol+		Vol +
	Vol-		Vol -
	Up		Up
	Down		Down
	Right		Right
	Left		Left
	OK		Ok
	SW Vol+		Shift + Vol +
	SW Vol-		Shift + Vol -
	Play		Play
	<<		<<
	>>		>>
	Pause		Pause
	I<<		I<<
	>>I		>>I
	Stop		Stop
	Sound Field		3D
	Audio		Dual
	Bluetooth RX/TX		Text
	Red		Red





	Original	Replacement	Original	Replacement
	Green			
	Yellow			
	Blue			

