

































































Original	Replacement
 Power	 Power
 Mute	 Mute
 1	 1
 2	 2
 3	 3
 4	 4
 5	 5
 6	 6
 7	 7
 8	 8
 9	 9
 0	 0
 TV/R	 TV/R
 Last	 Back
 Menu	 Menu
 Exit	 Exit
 Up / CH+	 Up

Original	Replacement
 Up / CH+	 Ch +
 Down / CH-	 Down
 Down / CH-	 Ch -
 Right / Vol+	 Right
 Right / Vol+	 Vol +
 Left / Vol-	 Left
 Left / Vol-	 Vol -
 OK	 Ok
 Info	 Info
 Sub-T	 Subt
 Audio	 Dual
 Text	 Text
 EPG	 Guide
 Favor	 Pre Ch
 Red / I<<	 Red
 Red / I<<	 I<<
 Green / >>I	 Green





Original	Replacement	Original	Replacement
 Green / >>	 >>		
 Yellow / <<	 Yellow		
 Yellow / <<	 <<		
 Blue / >>	 Blue		
 Blue / >>	 >>		
 Play/Pause	 Play		
 Play/Pause	 Pause		
 Stop	 Stop		
 Rec	 Rec		

