





Original		Replacement		Original		Replacement	
	Power		Power		Exit		Exit
	Mute		Mute		Up		Up
	1		1		Down		Down
	2		2		Right		Right
	3		3		Left		Left
	4		4		OK		Ok
	5		5		Vol+		Vol +
	6		6		Vol-		Vol -
	7		7		Sound		Shift + Dual
	8		8		PIC		Options
	9		9		CH+		Ch +
	0		0		CH-		Ch -
	Audio		Dual		Sleep		Sleep
	Recall		Back		Aspect		3D
	Tv-Menu		Menu		Freeze		Shift + Media
	Source		AV		Tv/Radio		TV/R
	CH.List		List		Text		Text





Original	Replacement	Original	Replacement
	EPG		Guide
	FAV		Pre Ch
	Info		Info
	Red		Red
	Green		Green
	Yellow		Yellow
	Blue		Blue
	Reveal		Eject
	Hold		D. Menu
	List		Smart
	Index		Shift + Info
	Subpage		Shift + Subt
	Size		Format
	MIX		Media
	Subtitle		Subt
	<<		<<
	>>		>>

