












Original	Replacement	Original	Replacement
	Power		Up
	Night		Down
	Surr		Right
	OPT		Left
	HDMI In		Ok
	HDMI ARC		Play
	USB		Pause
	AUX		
	Bluetooth/Pairing		
	Movie		
	Music		
	TV		
	Treble+		
	Treble-		
	Bass+		
	Bass-		
	Mute		

