














































Original	Replacement
 Power	 Power
 Mute	 Mute
 1	 1
 2	 2
 3	 3
 4	 4
 5	 5
 6	 6
 7	 7
 8	 8
 9	 9
 0 / TV/SAT	 0
 0 / TV/SAT	 TV/R
 Audio	 Dual
 Page+	 >>I
 Page-	 I<<
 Up	 Up

Original	Replacement
 Up	 Ch +
 Down	 Down
 Down	 Ch -
 Left	 Left
 Left	 Vol -
 Right	 Right
 Right	 Vol +
 OK	 Ok
 Menu	 Menu
 Exit	 Exit
 EPG	 Guide
 i	 Info
 Text	 Text
 FAV / Red	 Red
 FAV / Red	 Pre Ch
 Sleep	 Sleep
 AUD / Green	 Green




Original
Replacement

	RCL / Blue		Blue
	LANG / Yellow		Yellow
	LANG / Yellow		Options

Original
Replacement

