






























































































Original	Replacement	Original	Replacement
 Mute	 Mute / Dimmer	 Vol-	 Vol-
 Power	 Power	 *	 D.Menu / Top
 1	 1	 P-	 CH- / Page-
 2	 2	 Home	 Menu / Home
 3	 3	 Up	 Up
 4	 4	 =	 Setup / OPT /
 5	 5	 Left	 Left
 6	 6	 OK	 OK
 7	 7	 Right	 Right
 8	 8	 Back	 Back / Return
 9	 9	 Down	 Down
 PRE-CH	 Fav / Marker / PC	 Input	 AV / Input / RDS
 0	 0	 Exit	 Exit / Cancel / Clear
 List	 Smart / List	 Guide	 Guide / EPG / -/-
 Vol+	 Vol+	 Text	 Text / Goto
 [i]	 Info / Angle	 Lang	 Audio / Lang I/II
 P+	 CH+ / Page+	 Subt.	 Subtitle / EQ





Original	Replacement	Original	Replacement
	Red  Red / Netflix / Search		
	Green  Green / APP / Repeat		
	Yellow  Yellow / YouTube / Repeat		
	Blue  Blue / Prime Video / Random		
	<<  << / Tune-		
	Pause  Pause / Step / Freeze		
	>>  >> / Tune+		
	Zoom  Zoom / Size		
	Play  Play / Slow		
	Stop  Stop / Hold		
	Netflix  +  Shift + Red / Netflix /		

