







































































Original		Replacement		Original		Replacement	
	Power		Power		Play		Play
	Library		Smart		Stop		Stop
	Mute		Mute		Pause		Pause
	1		1		>>		>>
	2		2		>		>>
	3		3		Up		Up
	4		4		Left		Left
	5		5		OK		Ok
	6		6		Right		Right
	7		7		Down		Down
	8		8		Vol +		Vol +
	9		9		Vol -		Vol -
	0		0		Guide		Guide
	Rec		Rec		Menu		Menu
	Last		Pre Ch		Prog +		Ch +
	I<		I<<		Prog -		Ch -
	<<		<<		Back		Back





Original	Replacement	Original	Replacement
Info	Info		
Text	Text		
Exit	Exit		
Red	Red		
Green	Green		
Yellow	Yellow		
Blue	Blue		
AD	Shift + Subt		
Subt	Subt		
Audio	Dual		
A/V	AV		
HDMI	Media		
Wide	Format		

