










| Original | Replacement |
|--|---|
|  Power |  Power |
|  Tv/AV |  AV / Input / RDS |
|  1 |  1 |
|  2 |  2 |
|  3 |  3 |
|  4 |  4 |
|  5 |  5 |
|  6 |  6 |
|  7 |  7 |
|  8 |  8 |
|  9 |  9 |
|  -/-- |  Shift + Guide / EPG / -/-- |
|  0 |  0 |
|  Back |  Back / Return |
|  Vol+ |  Vol+ |
|  Scan |  Smart / List |
|  P+ |  CH+ / Page+ |

| Original | Replacement |
|--|---|
|  Vol- |  Vol- |
|  Zoom |  Zoom / Size |
|  P- |  CH- / Page- |
|  Up |  Up |
|  Left |  Left |
|  OK/Select |  OK |
|  Right |  Right |
|  Menu |  Menu / Home |
|  Down |  Down |
|  Mute |  Mute / Dimmer |
|  Red / Picture |  Red / Netflix / Search |
|  Red / Picture |  Picture / Format |
|  Green / Sound |  Green / APP / Repeat |
|  Green / Sound |  Sound / Title |
|  Yellow / Sleep |  Yellow / YouTube / Repeat |
|  Yellow / Sleep |  Sleep / Timer |
|  Blue / Call |  Blue / Prime Video / Random |



