







































































Original	Replacement	Original	Replacement
	Power		Power
	Red		Red
	Green/Cass.		Green
	Yellow/Prog		Yellow
	Blue/Mem		Blue
	Violet/Status		Smart
	Exit		Exit
	Menu		Menu
	Up		Up
	Down		Down
	Right		Right
	Left		Left
	OK		Ok
	Vol+		Vol +
	Vol-		Vol -
	Mute		Mute
	PR+		Ch +
	PR-		Ch -
	1		1
	2		2
	3		3
	4		4
	5		5
	6		6
	7		7
	8		8
	9		9
	0		0
	AV		AV
	Index/Mark		Info
	0000		Media
	SP/LP		Format
	<<		<<
	Play		Play































































	Original	Replacement		Original	Replacement
	>>		>>		
	Rec		Rec		
	Stop		Stop		
	Pause		Pause		





Original	Replacement	Original	Replacement
 Power	 Power	 PR-	 Ch -
 Red	 Red	 1	 1
 Green/Cass.	 Green	 2	 2
 Yellow/Prog	 Yellow	 3	 3
 Blue/Mem	 Blue	 4	 4
 Violet/Status	 Smart	 5	 5
 Menu	 Menu	 6	 6
 Exit	 Exit	 7	 7
 Up	 Up	 8	 8
 Down	 Down	 9	 9
 Right	 Right	 0	 0
 Left	 Left	 AV	 AV
 OK	 Ok		
 Vol+	 Vol +		
 Vol-	 Vol -		
 Mute	 Mute		
 PR+	 Ch +		

