



Original	Replacement
 Power	 Power
 Mute	 Mute
 1	 1
 2	 2
 3	 3
 4	 4
 5	 5
 6	 6
 7	 7
 8	 8
 9	 9
 0	 0
 Menu	 Menu
 Exit	 Exit
 Up	 Up
 Down	 Down
 Right	 Right

Original	Replacement
 Left	 Left
 OK/List	 Ok
 PR+	 Ch +
 PR-	 Ch -
 Vol+	 Vol +
 Vol-	 Vol -
 P+/↑	 >>
 P-/↓	 <<
 EPG	 Guide
 Info	 Info
 SAT	 Smart
 Tv/Radio	 TV/R
 Multi Pict	 Format
 ←PR	 Back
 FAV	 Pre Ch
 Audio	 Dual
 Red/Text	 Red



