



| Original  |         | Sustituto   |            | Original  |           | Sustituto   |       |
|---|---------|---|------------|---|-----------|---|-------|
|    | Power   |    | Power      |    | CH+       |    | CH +  |
|    | Source  |    | Audio      |    | CH-       |    | CH -  |
|    | 1       |    | 1          |    | Menu      |    | MENU  |
|    | 2       |    | 2          |    | Back      |    | BACK  |
|    | 3       |    | 3          |    | Info      |    | INFO  |
|    | 4       |    | 4          |    | OK        |    | OK    |
|    | 5       |    | 5          |    | Up        |    | UP    |
|    | 6       |    | 6          |    | Down      |    | DOWN  |
|    | 7       |    | 7          |    | Right     |    | RIGHT |
|    | 8       |    | 8          |    | Left      |    | LEFT  |
|   | 9       |   | 9          |   | SAP       |   | MEDIA |
|  | 0       |  | 0          |  | Mode/Auto |  | OPT+  |
|  | PREV.CH |  | P/C / FAV  |  | Freeze    |  | Pause |
|  | .       |  | -/-- / EPG |  | Sleep     |  | VOD   |
|  | Mute    |  | MUTE       |  | Format    |  | V-FOR |
|  | Vol+    |  | VOL +      |   |           |   |       |
|  | Vol-    |  | VOL -      |   |           |   |       |

