






































































Original	Sustituto
 Power	 Power
 Mute	 Mute / Dimmer
 Play/Pause/Hold	 Play / Slow
 Pause	 Pause / Step / Freeze
 Stop/Size	 Stop / Hold
 Rec Menu	 Rec / Rec Mode
 <<	 << / Tune-
 >> / Cancel	 >> / Tune+
 I<< / Index	 I<< / Preset-
 >>I/Reveal	 >>I / Preset+
 Nicam	 Audio / Lang I/II
 Subtitle	 Subtitle / EQ
 Aspect	 Picture / Format
 Sleep	 Sleep / Timer
 Tv	 TV/Radio /
 Subpage	 D.Menu / Top
 PC Auto	 Setup / OPT /

Original	Sustituto
 Text	 Text / Goto
 Source	 AV / Input / RDS
 Menu	 Menu / Home
 Up	 Up
 ??	 Info / Angle
 Left	 Left
 OK	 OK
 Right	 Right
 Exit	 Exit / Cancel / Clear
 Down	 Down
 Back	 Back / Return
 Vol+	 Vol+
 List	 Smart / List
 CH+	 CH+ / Page+
 Vol-	 Vol-
 Display	 Display / Media
 CH-	 CH- / Page-





Original	Sustituto
	1
	2
	3
	4
	5
	6
	7
	8
	9
	Guide / EPG / -/--
	0
	Fav / Marker / PC
	Red / Netflix / Search
	Green / APP / Repeat
	Yellow / YouTube / Repeat
	Blue / Prime Video / Random
	+ Shift + Pause / Step / Freeze

Original	Sustituto
	+ Shift + TV/Radio / Program
	+ Shift + Display / Media
	+ Shift + Guide / EPG / -/--
	+ Shift + Green / APP / Repeat
	+ Shift + Yellow / YouTube / Repeat

