






















































Original	Sustituto	Original	Sustituto
	Power		Smart Hub
	Source		VOD
	HDMI		VOL +
	1		VOL -
	2		CH +
	3		CH -
	4		EPG 1. / - / EPG
	5		MENU
	6		OPT+
	7		INFO
	8		UP
	9		OK
	0		DOWN
	TTX/MIX		RIGHT
	PRE-CH		LEFT
	Mute		BACK
	CH List		EXIT
			Red (A)
			SRC
			MEDIA
			1
			2
			3
			4
			5
			6
			7
			8
			9
			0
			TEXT
			P/C / FAV
			MUTE
			TV/R



