



Original	Sustituto	Original	Sustituto
	Power		Power
	Mute		Mute
	DVB		Smart
	[/≡]		Options
	[≡]		Text
	[≡O]		Subt
	[≡◆]/FAV-		AV
	[≡+]/FAV+		Dual
	[≡X]/EPG		Guide
	[≡?]/Radio		TV/R
	Red/PP		Red
	Green/♪		Green
	Yellow/[ ]		Yellow
	Blue		Blue
	[++]		3D
	≡i		Info
	Menu		Menu
	DVB Menu		Media
	OK		Ok
	Up		Up
	Down		Down
	Right		Right
	Left		Left
	Vol+		Vol +
	Vol-		Vol -
	P+		Ch +
	P-		Ch -
	PIP		Format
	Recall		Pre Ch
	Zap		Back
	Freeze		Pause
	←AV		Shift + AV
	AV→		Shift + Format
	16:9		D. Menu



