







































































Original	Sustituto	Original	Sustituto
 Power	 Power	 World	 Media
 Source	 AV	 Vol+	 Vol +
 1	 1	 Vol-	 Vol -
 2	 2	 PR+	 Ch +
 3	 3	 PR-	 Ch -
 4	 4	 OK	 Ok
 5	 5	 Up	 Up
 6	 6	 Down	 Down
 7	 7	 Right	 Right
 8	 8	 Left	 Left
 9	 9	 Back	 Back
 0	 0	 Exit	 Exit
 TV	 TV/R	 i	 Info
 Mute	 Mute	 Guide	 Guide
 Recall	 Pre Ch	 /Music/Photo/Movi	 Dual
 Menu	 Menu	 [≡]/Text	 Text
 Q.Menu	 D. Menu	 */o	 Format



