
























































Original	Sustituto
	 Ok
	 Power
	 Back
	 Media
	 Up
	 Down
	 Left
	 Right
	 3D
	 Mute
	 Ch +
	 Ch -
	 Vol +
	 Vol -
	 2
	 8

Original	Sustituto




































Original	Sustituto
Power	 Power
Wheel Down	 +  Shift + Down
OK	 Ok
Up	 Up
Down	 Down
Wheel Up	 +  Shift + Up
Right	 Right
Left	 Left
Back	 Back
Home / Smart	 Smart
3D	 3D
123 / Q.Menu	 +  Shift + Ok
Vol +	 Vol +
Vol -	 Vol -
Mute	 Mute
P +	 Ch +
P -	 Ch -

Original	Sustituto
Ratio	 Format
List	 List
Q.Menu	 +  Shift + Menu
Subtitle	 Subt
Settings	 +  Shift + Options
AD / PIP	 Dual
>>	 >>
>>>	 >>I
Play	 Play
<<<	 <<<
<<	 I<<
Rec	 Rec
Pause	 Pause
Stop / Live TV	 Stop
AV Mode	 +  Shift + AV
Text	 Text
FAV	 +  Shift + Pre Ch





Original	Sustituto	Original	Sustituto
Exit		Exit	Exit
TV / PC	 + 	Shift + Smart	Shift + Smart
Input		AV	AV
TV / Radio		TV/R	TV/R
Blue		Blue	Blue
Yellow		Yellow	Yellow
Green		Green	Green
Red		Red	Red
0		0	0
AD	 + 	Shift + Subt	Shift + Subt
Search	 + 	Shift + TV/R	Shift + TV/R
Live Menu		Menu	Menu
Recent		Pre Ch	Pre Ch
Live Zoom		Eject	Eject
App	 + 	Shift + Media	Shift + Media
Guide		Guide	Guide
Info		Info	Info

Original	Sustituto	Original	Sustituto
T.Opt		Options	Options
Q.View		D. Menu	D. Menu
Energy Saving	 + 	Shift + 3D	Shift + 3D
9		9	9
8		8	8
7		7	7
6		6	6
5		5	5
4		4	4
3		3	3
2		2	2
1		1	1
My APPS		Media	Media

