








































Original	Sustituto
 Power	 Power
 Source	 AV
 1	 1
 2	 2
 3	 3
 4	 4
 5	 5
 6	 6
 7	 7
 8	 8
 9	 9
 0	 0
 Info	 Info
 List	 List
 Vol+	 Vol +
 Vol-	 Vol -
 CH+	 Ch +

Original	Sustituto
 CH-	 Ch -
 Mute/SAP	 Mute
 Home	 Smart
 */Setting	 Menu
 3D	 3D
 Exit	 Exit
 Back	 Back
 Up	 Up
 Down	 Down
 Right	 Right
 Left	 Left
 Wheel Up	 >>
 Wheel Down	 <<
 OK	 Ok
 [!!!]	 Options
 Red	 Red
 Green	 Green



