













































Original	Sustituto
 Standby	 Power
 STB PWR	 +  Shift + Power
 1	 1
 2	 2
 3	 3
 4	 4
 5	 5
 6	 6
 7	 7
 8	 8
 9	 9
 0/Quick Access	 0
 List	 List
 AD	 Subt
 Vol+	 Vol +
 Vol-	 Vol -
 P+	 Ch +

Original	Sustituto
 P-	 Ch -
 Mute	 Mute
 Micro/Q	 Format
 Home/Recents	 TV/R
 *	 Menu
 Back/Exit	 Back
 Guide	 Guide
 Mouse Up	 >>
 Mouse Down	 <<
 OK	 Ok
 Up	 Up
 Down	 Down
 Right	 Right
 Left	 Left
 Netflix	 +  Shift + Media
 Amazon	 Media
 Source	 AV





Original		Sustituto		Original		Sustituto	
	Text		Text				
	T.Opt/Magic Link		Options				
	Info		Info				
	Play		Play				
	Pause		Pause				
	Live		3D				
	Red		Red				
	Green		Green				
	Yellow		Yellow				
	Blue		Blue				

