









Original	Sustituto	Original	Sustituto
	Power		Power
	Source		AV
	1		1
	2		2
	3		3
	4		4
	5		5
	6		6
	7		7
	8		8
	9		9
	0		0
	TIX/MIX		Text
	PRE-CH		Pre Ch
	Mute		Mute
	CH.List		List
	Vol+		Vol +

Original	Sustituto	Original	Sustituto
	Vol-		Vol -
	PR+		Ch +
	PR-		Ch -
	Menu		Menu
	Tools		Options
	Guide		Guide
	Info		Info
	Exit		Exit
	Return		Back
	Media.P		Media
	Enter		Ok
	Up		Up
	Down		Down
	Right		Right
	Left		Left
	Red		Red
	Green		Green





Original	Sustituto	Original	Sustituto
 Yellow	 Yellow		
 Blue	 Blue		
 PIP	 Format		
 AD/Subt.	 Subt		
 Ball	 TV/R		
 Stop	 Stop		
 Play	 Play		
 <<<	 <<<		
 >>>	 >>>		
 Pause	 Pause		

Original	Sustituto

