



Original	Sustituto
	 Power
	 Eject / Surround
	 Subtitle / EQ
	 1
	 2
	 3
	 Info / Angle
	 4
	 5
	 6
	 Audio / Lang I/II
	 7
	 8
	 9
	 Display / Media
	 Sleep / Timer
	 Guide / EPG / -/--

Original	Sustituto
	 0
	 Smart / List
	 Sound / Title
	 TV/Radio /
	 Exit / Cancel / Clear
	 Setup / OPT /
	 Up
	 Left
	 OK
	 Right
	 Down
	 Back / Return
	 Menu / Home
	 Picture / Format
	 << / Tune-
	 Pause / Step / Freeze
	 Play / Slow





Original	Sustituto
>>I	>>I / Preset+
>>	>> / Tune+
Stop	Stop / Hold
I<<	I<< / Preset-
Zoom	Zoom / Size
Step	Shift + Pause / Step /
Slow	Shift + Play /
Vol+	Vol+
Mute	Mute / Dimmer
3D	Shift + 3
Ran	D.Menu / Top
Vol-	Vol-
N/P	Red / Netflix / Search
R/L	Blue / Prime Video / Random
A/B	Yellow / YouTube / Repeat
Repeat	Green / APP / Repeat

Original	Sustituto

