







































































| Original | Sustituto | Original | Sustituto |
|---|----------------|---|--------------------------|
|  | Power |  | Power |
|  | [≡] |  | Text / Goto |
|  | [≡?] |  | D.Menu / Top |
|  | [...] |  | Subtitle / EQ |
|  | [≡+] |  | Eject / Surround |
|  | [≡o] |  | Sound / Title |
|  | [≡◆] |  | Zoom / Size |
|  | 1 |  | 1 |
|  | 2 |  | 2 |
|  | 3 |  | 3 |
|  | 4 |  | 4 |
|  | 5 |  | 5 |
|  | 6 |  | 6 |
|  | 7 |  | 7 |
|  | 8 |  | 8 |
|  | 9 |  | 9 |
|  | Recall |  | Fav / Marker / PC |
|  | 0 |  | 0 |
|  | Source |  | AV / Input / RDS |
|  | ATV |  | Shift + Smart / List |
|  | DTV |  | Shift + Display / Media |
|  | EPG |  | Guide / EPG / -/- |
|  | Radio |  | TV/Radio / |
|  | I/II/I+II/▼/O) |  | Audio / Lang I/II |
|  | Vol+ |  | Vol+ |
|  | P+ |  | CH+ / Page+ |
|  | P.Info |  | Display / Media |
|  | Mute |  | Mute / Dimmer |
|  | Vol- |  | Vol- |
|  | P- |  | CH- / Page- |
|  | [i+] |  | Info / Angle |
|  | [<>] |  | Picture / Format |
|  | Sleep |  | Sleep / Timer |
|  | AV Mode |  | Shift + AV / Input / RDS |



