







































































| Original | | Sustituto | | Original | | Sustituto | |
|---|-----------------|---|------------|---|------------|---|-----------|
|  | Standby |  | Power |  | Timer |  | -/- / EPG |
|  | Teletex |  | TEXT |  | Menu |  | MENU |
|  | Red |  | Red (A) |  | Mute |  | MUTE |
|  | Green/[] Smart |  | Green (B) |  | P<P |  | P/C / FAV |
|  | Yellow/Smart |  | Yellow (C) |  | OK |  | OK |
|  | Blue |  | Blue (D) |  | Up |  | UP |
|  | 1 |  | 1 |  | Down |  | DOWN |
|  | 2 |  | 2 |  | Right |  | RIGHT |
|  | 3 |  | 3 |  | Left |  | LEFT |
|  | 4 |  | 4 |  | P+ |  | CH + |
|  | 5 |  | 5 |  | P- |  | CH - |
|  | 6 |  | 6 |  | Vol+ |  | VOL + |
|  | 7 |  | 7 |  | Vol- |  | VOL - |
|  | 8 |  | 8 |  | Play |  | Play |
|  | 9 |  | 9 |  | Stop |  | Stop |
|  | 0 |  | 0 |  | Record/OTR |  | Rec |
|  | Clear |  | EXIT |  | << |  | Rewind |



