







































































Original	Sustituto
 Power	 Power
 Select Drive	 List
 1	 1
 2	 2
 3	 3
 4	 4
 5	 5
 6	 6
 7	 7
 8	 8
 9	 9
 0	 0
 Last View	 Pre Ch
 Radio/Tv	 TV/R
 CH/Page Up	 Ch +
 CH/Page Down	 Ch -
 Internet	 Smart

Original	Sustituto
 Skipe	 Media
 I<<	 I<<
 >>I	 >>I
 << Slow Search	 <<
 Slow Search >>	 >>
 Stop	 Stop
 Pause/Pause Live	 Pause
 Play/x.1.3	 Play
 Rec	 Rec
 i/Status	 Info
 X/Exit	 Exit
 Option	 Options
 Return	 Back
 Guide	 Guide
 Direct Navigator/PopUp	 D. Menu
 Function Menu	 Menu
 Up	 Up





Original	Sustituto
Right/ >	
Left/<	
	+ Shift + Rec
	Text
	Subt
	Format
	3D
	Sleep
	Dual
	AV
	Mute

Original	Sustituto
	+ Shift + Format
	+ Shift + 3D
	+ Shift + Power
	+ Shift + AV
	Vol +
	Vol -
	+ Shift + Ch +
	+ Shift + Ch -

