



| Original | Sustituto |
|---|--|
|  Standby |  Power |
|  Teletext |  Text |
|  Red |  Red |
|  Green/[] Smart |  Green |
|  Yellow/Smart |  Yellow |
|  Blue |  Blue |
|  1 |  1 |
|  2 |  2 |
|  3 |  3 |
|  4 |  4 |
|  5 |  5 |
|  6 |  6 |
|  7 |  7 |
|  8 |  8 |
|  9 |  9 |
|  0 |  0 |
|  Clear |  Exit |

| Original | Sustituto |
|--|---|
|  Timer |  AV |
|  Menu |  Menu |
|  Mute |  Mute |
|  P<P |  Pre Ch |
|  OK |  Ok |
|  Up |  Up |
|  Down |  Down |
|  Right |  Right |
|  Left |  Left |
|  P+ |  Ch + |
|  P- |  Ch - |
|  Vol+ |  Vol + |
|  Vol- |  Vol - |
|  Play |  Play |
|  Stop |  Stop |
|  Record/OTR |  Rec |
|  << |  << |



