



Original	Sustituto	Original	Sustituto
	Power		Power
	Play		Play
	Stop		Stop
	Pause		Pause
	<<		<<
	>>		>>
	I<<		I<<
	>>I		>>I
	TV/TXT		Text
	Cancel		Back
	Reveal		Eject
	Hold		Media
	Size		3D
	Subpage		D. Menu
	Index		List
	Red		Red
	Green		Green
	Yellow		Yellow
	Blue		Blue
	CH+		Ch +
	CH-		Ch -
	Vol+		Vol +
	Vol-		Vol -
	Menu		Menu
	Source		AV
	DVB		Smart
	Exit		Exit
	OK		Ok
	Up		Up
	Down		Down
	Right		Right
	Left		Left
	1		1
	2		2





	Original	Sustituto		Sustituto
	3		3	
	4		4	
	5		5	
	6		6	
	7		7	
	8		8	
	9		9	
	0		0	
	-/--	+	Shift +	Guide
	Recall			Pre Ch
	Picture	+	Shift +	Format
	Sound	+	Shift +	Dual
	Nicam/A2			Options
	Mute			Mute
	Sleep			Sleep
	Tv/Radio			TV/R
	FAV	+	Shift +	Pre Ch

	Original	Sustituto		Sustituto
	FAV+	+	Shift +	Ch +
	FAV-	+	Shift +	Ch -
	Pic Format			Format
	Subtitle			Subt
	Text	+	Shift +	Text
	Display			Info
	Language			Dual
	EPG			Guide

