
































































Original	Sustituto
 Power	 Power
 Source	 AV
 Sleep	 Sleep
 Picture Mode	 Format
 Sound Mode	 Shift + Dual
 1	 1
 2	 2
 3	 3
 4	 4
 5	 5
 6	 6
 7	 7
 8	 8
 9	 9
 0	 0
 [<>]/Aspect	 3D
 Guide	 Guide

Original	Sustituto
 Back	 Back
 Eco	 Shift + 3D
 Menu	 Menu
 i	 Info
 Audio	 Dual
 Up	 Up
 Down	 Down
 Right	 Right
 Left	 Left
 OK	 Ok
 Vol+	 Vol +
 Vol-	 Vol -
 Mute	 Mute
 P+	 Ch +
 P-	 Ch -
 Red	 Red
 Green	 Green





Original	Sustituto
 Yellow	 Yellow
 Blue	 Blue
 Fun-Link	 Media
 [...]	 Subt
 [≡◆]	 D. Menu
 [≡o]	 Smart
 [≡+]	 Options
 [≡=]	 Text
 [≡=?]	 TV/R
 [≡i]	 List
 Play	 Play
 Pause	 Pause
 Stop	 Stop
 >>	 >>
 <<	 <<
 >>	 >>
 <<	 <<

Original	Sustituto

