







































































Original	Sustituto	Original	Sustituto
	Audio		Dual
	[]		Format
	Power		Power
	[*]/SV		Subt
	V≡/LP		Options
	[≡I]/000		Guide
	Mute/Timer		Mute
	1		1
	2		2
	3		3
	4		4
	5		5
	6		6
	7		7
	8		8
	9		9
	0		0
	T		Smart
	Pause		Pause
	M		Menu
	E		3D
	i		Info
	Rec		Rec
	Up		Up
	Right		Right
	Down		Down
	Left		Left
	OK		Ok
	Red		Red
	<<		<<
	Green		Green
	Stop		Stop
	Yellow		Yellow
	Play		Play









































































	Original	Sustituto	Original	Sustituto
	Blue	D		
	>>			









Original		Sustituto		Original		Sustituto	
	Mute/Timer		Mute		<<		<<
	Power		Power		Stop		Stop
	1		1		Play		Play
	2		2		>>		>>
	3		3		Pause		Pause
	4		4		Rec		Rec
	5		5		M		Menu
	6		6		E		3D
	7		7		Audio		Dual
	8		8		[≡]/000		Guide
	9		9		V≡/LP		Options
	0		0		[]		Format
	Up		Up		[*]/SV		Subt
	Down		Down		T		Smart
	OK		Ok		i		Info
	Right		Right		Red		Red
	Left		Left		Green		Green









































































Original		Sustituto		Original		Sustituto	
	Yellow		Yellow				
	Blue		Blue				





Original	Sustituto	Original	Sustituto
	Power		Power
	1		1
	2		2
	3		3
	4		4
	5		5
	6		6
	7		7
	8		8
	9		9
	0		0
	[]		Format
	Audio		Dual
	[*]/SV		Subt
	V≡/LP		Options
	[=] /000		Guide
	Mute/Timer		Mute
	T		Smart
	M		Menu
	E		3D
	Up		Up
	Down		Down
	Right		Right
	Left		Left
	OK		Ok
	Red		Red
	Green		Green
	Yellow		Yellow
	Blue		Blue
	<<		<<
	Stop		Stop
	Play		Play
	>>		>>
	Pause		Pause

