







































































Original	Sustituto	Original	Sustituto
 Power	 Power	 Yellow	 Yellow
 Play	 Play	 Index	 List
 Pause	 Pause	 Blue	 Blue
 <<<	 <<<	 CH+	 Ch +
 >>>	 >>>	 CH-	 Ch -
  <<<	  <<<	 Input	 AV
 >>>	 >>>	 Vol+	 Vol +
 Stop	 Stop	 Vol-	 Vol -
 Rec	 Rec	 Mute	 Mute
 Tv/TXT	 Text	 Menu	 Menu
 Cancel	 Shift + Exit	 Exit	 Exit
 Hold	 Options	 DVB	 Smart
 Reveal	 D. Menu	 Up	 Up
 Size	 3D	 Down	 Down
 Red	 Red	 Right	 Right
 Green	 Green	 Left	 Left
 Subpage	 Eject	 OK	 OK





Original	Sustituto
1	1
2	2
3	3
4	4
5	5
6	6
7	7
8	8
9	9
0	0
-/--	SHIFT + -/-- Shift + Guide
↻	RETURN BACK Back
PICTURE	SHIFT + PICTURE FORMAT Shift + Format
SOUND	SHIFT + SOUND DUAL Shift + Dual
NICAM/A2	APP MEDIA Media
SLEEP	PROG SLEEP Sleep
TV/RADIO	SEARCH TV/R TV/R

Original	Sustituto
FAV	PRE-CH Pre Ch
FAV+	SHIFT + + CH Shift + Ch +
FAV-	SHIFT + - CH Shift + Ch -
SUBTITLE	AD SUBT Subt
PIC FORMAT	PICTURE FORMAT Format
LANGUAGE	SOUND DUAL Dual
TEXT	SHIFT + REPEAT TEXT Shift + Text
EPG	-/-- GUIDE Guide
DISPLAY	DISPLAY INFO Info

