







































































Original	Sustituto	Original	Sustituto
 Power	 Power	 Menu	 Menu
 Mute	 Mute	 EPG	 Guide
 1	 1	 Exit	 Exit
 2	 2	 Up / CH + / I<<	 Up
 3	 3	 Down / CH - / >>I	 Down
 4	 4	 Right / Vol +	 Right
 5	 5	 Left / Vol -	 Left
 6	 6	 OK	 Ok
 7	 7	 Up / CH + / I<<	 I<<
 8	 8	 Down / CH - / >>I	 >>I
 9	 9	 Up / CH + / I<<	 Ch +
 0	 0	 Down / CH - / >>I	 Ch -
 FAV	 Shift + Pre Ch	 Left / Vol -	 Vol -
 Recall	 Pre Ch	 Right / Vol +	 Vol +
 Game	 Media	 Red / Zoom	 Red
 Auto	 Smart	 Green / Lan/Audio	 Green
 Info	 Info	 Yellow /	 Yellow

Original	Sustituto	Original	Sustituto
 MUTE	 MUTE	 TV	 AUX
 MUTE	 MUTE	 DVD	 REC MODE
 1	 1	 SAT	 PLAY MODE
 2	 2	 AUX	 PAUSE
 3	 3	 SOUND	 STOP
 4	 4	 AD	 DISC NAV
 5	 5	 SETTINGS	 LIST
 6	 6	 OPT	 DUAL
 7	 7	 ECO	 SUBT
 8	 8	 3D	 SEARCH
 9	 9	 TIMER	 PICTURE
 0	 0	 AV	 SLEEP
 FAV	 FAV	 E-MANUAL	 TV/R
 Recall	 Recall	 REPEAT	 FORMAT
 GAME	 GAME	 ZOOM	 3D
 AUTO	 AUTO	 TEXT	 TIMER
 INFO	 INFO	 D.MENU	 AV
 POWER	 POWER	 TEXT	 AV



Play/Pause

