







































































Original	Sustituto	Original	Sustituto
	Power		Power
	Audio Monitor		Audio / Lang I/II
	Wide		Picture / Format
	Tv/Video		TV/Radio /
	[≡]		Text / Goto
	Tv/Video		AV / Input / RDS
	Vol+		Vol+
	[ ]		Info / Angle
	Prog+		CH+ / Page+
	Vol-		Vol-
	Display		Display / Media
	Prog-		CH- / Page-
	1		1
	2		2
	3		3
	4		4
	5		5
	6		6
	7		7
	8		8
	9		9
	-/--		Guide / EPG / -/--
	0		0
	Red		Red / Netflix / Search
	Green		Green / APP / Repeat
	Yellow		Yellow / YouTube / Repeat
	Blue		Blue / Prime Video / Random



























Original		Sustituto		Original		Sustituto	
	Eject		Eject / Surround		4		4
	Power		Power		5		5
	Audio Monitor		Audio / Lang I/II		6		6
	Wide		Picture / Format		7		7
	Counter Remain		Yellow / YouTube / Repeat		8		8
	[ I ]		Info / Angle		9		9
	I> Slow		Shift + Play /		-/--		Guide / EPG / -/--
	X2		Shift + >> /		0		0
	I<< Index Search		I<< / Preset-		Input Select		AV / Input / RDS
	Index Search >>I		>>I / Preset+		Vol+		Vol+
	Display		Display / Media		Prog+		CH+ / Page+
	SP/LP		Green / APP / Repeat		Vol-		Vol-
	Clear		Exit / Cancel / Clear		Prog-		CH- / Page-
	Tv/Video		TV/Radio /		Rec		Rec / Rec Mode
	1		1		Pause		Pause / Step / Freeze
	2		2		Up		Up
	3		3		Timer		Sleep / Timer





Original	Sustituto	Original	Sustituto
	Menu		Menu / Home
	Smart Search		Smart / List
	Smart Search		Red / Netflix / Search
	<<		<< / Tune-
	Left		Left
	Play		Play / Slow
	OK		OK
	>>		>> / Tune+
	Right		Right
	Stop		Stop / Hold
	Down		Down

