



























Original	Sustituto	Original	Sustituto
	Power		Power
	Home		Smart
	Back		Back
	Micro		Dual
	Tv		TV/R
	Mouse Down		>>
	Mouse Up		<<
	Up		Up
	Down		Down
	Right		Right
	Left		Left
	OK		Ok
	Red		Red
	Green		Green
	Yellow		Yellow
	Blue		Blue
	Vol+		Vol +
	Vol-		Vol -
	123/Input		AV
	3D		3D
	Mute/AD		Mute
	P+		Ch +
	P-		Ch -





Original	Sustituto
 Power	 Power
 Wheel Down	 Shift + Down
 OK	 Ok
 Up	 Up
 Down	 Down
 Wheel Up	 Shift + Up
 Right	 Right
 Left	 Left
 Back	 Back
 Home / Smart	 Smart
 3D	 3D
 123 / Q.Menu	 Shift + Ok
 Vol +	 Vol +
 Vol -	 Vol -
 Mute	 Mute
 P +	 Ch +
 P -	 Ch -

Original	Sustituto
Ratio	 Format
List	 List
Q.Menu	 Shift + Menu
Subtitle	 Subt
Settings	 Shift + Options
AD / PIP	 Dual
>>	 >>
>>>	 >>I
Play	 Play
<<<	 <<<
<<	 I<<<
Rec	 Rec
Pause	 Pause
Stop / Live TV	 Stop
AV Mode	 Shift + AV
Text	 Text
FAV	 Shift + Pre Ch





Original	Sustituto	Original	Sustituto
Exit	 Exit	T.Opt	 Options
TV / PC	 +  Shift + Smart	Q.View	 D. Menu
Input	 AV	Energy Saving	 +  Shift + 3D
TV / Radio	 TV/R	9	 9
 Blue	 D	8	 8
 Yellow	 C	7	 7
 Green	 B	6	 6
 Red	 A	5	 5
0	 0	4	 4
AD	 +  Shift + Subt	3	 3
Search	 +  Shift + TV/R	2	 2
Live Menu	 Menu	1	 1
Recent	 Pre Ch	My APPS	 Media
Live Zoom	 Eject		
App	 +  Shift + Media		
Guide	 Guide		
Info	 Info		

