



































































Original	Sustituto	Original	Sustituto
	Power		Power
	Input		AV
	TV / DVD		TV/R
	abc		Text
	List		List
	1		1
	2		2
	3		3
	4		4
	5		5
	6		6
	7		7
	8		8
	9		9
	0		0
	Mute		Mute
	Menu		Menu
	Subt		Subt
	-/--		Guide
	DVD Menu		D. Menu
	Img +		Ch +
	Img -		Ch -
	Up		Up
	Right / >>		Right
	Down		Down
	Left / <<		Left
	<<		<<
	>>		>>
	Play / Enter		Ok
	Play		Play
	Vol +		Vol +
	Vol -		Vol -
	Eject		Eject
	Tools		Options



