







































































| Original  | Sustituto   | Original  | Sustituto   |
|---|---|---|---|
|  Standby     |  Shift + Power               |  A/B/C/D/E     |  AV / Input / RDS      |
|  Power       |  Power                       |  < Preset      |  I<< / Preset-         |
|  Scene 1     |  Red / Netflix / Search      |  Preset >      |  >>I / Preset+         |
|  Scene 2     |  Green / APP / Repeat        |  Sleep         |  Sleep / Timer         |
|  Scene 3     |  Yellow / YouTube / Repeat   |  Level         |  Smart / List          |
|  Scene 4     |  Blue / Prime Video / Random |  Up            |  Up                    |
|  CD          |  3                           |  Menu          |  Menu / Home           |
|  MD/CD-R     |  4                           |  Audio Sel     |  Audio / Lang I/II     |
|  Tuner       |  6                           |  Left          |  Left                  |
|  Multi CH In |  8                           |  Enter         |  OK                    |
|  DVD         |  2                           |  Right         |  Right                 |
|  DTV/CBL     |  1                           |  Night         |  Exit / Cancel / Clear |
|  DVR        |  5                          |  Return       |  Back / Return        |
|  V-AUX     |  7                         |  Down        |  Down                |
|  Vol-      |  Vol-                      |  Display     |  Display / Media     |
|  Mute      |  Mute / Dimmer             |  Sur. Decode |  Sound / Title       |
|  Vol+      |  Vol+                      |  Straight    |  Text / Goto         |





| Original   | Sustituto        | Original | Sustituto |
|------------|------------------|----------|-----------|
| < Prog     | CH- / Page-      |          |           |
| Prog >     | CH+ / Page+      |          |           |
| Enhancer   | TV/Radio /       |          |           |
| Info       | Info / Angle     |          |           |
| EON        | Setup / OPT /    |          |           |
| Mode-PTY   | Picture / Format |          |           |
| Seek-Start | D.Menu / Top     |          |           |
|            |                  |          |           |
|            |                  |          |           |
|            |                  |          |           |
|            |                  |          |           |
|            |                  |          |           |
|            |                  |          |           |
|            |                  |          |           |
|            |                  |          |           |
|            |                  |          |           |
|            |                  |          |           |
|            |                  |          |           |
|            |                  |          |           |
|            |                  |          |           |
|            |                  |          |           |
|            |                  |          |           |

