












































Original	Sustituto
 Power	 Power
 Input TV	 TV/R
 Input	 AV
 ARC	 Media
 *+	 Shift + Right
 -*	 Shift + Left
 Text	 Text
 PIP	 3D
 Size	 Format
 Position	 Options
 Red/PIP PR-	 Red
 Green/PIP PR+	 Green
 Yellow/Swap	 Yellow
 Blue/PIP Input	 Blue
 Exit	 Exit
 List	 List
 Menu	 Menu

Original	Sustituto
 I/II	 Dual
 Sleep	 Sleep
 Up	 Up
 Down	 Down
 Right	 Right
 Left	 Left
 OK	 Ok
 Vol+	 Vol +
 Vol-	 Vol -
 Mute	 Mute
 PR+	 Ch +
 PR-	 Ch -
 Q.View	 Smart
 1	 1
 2	 2
 3	 3
 4	 4





	Original	Sustituto	Original	Sustituto
	Power			8
	Input			9
	Stop			0
	Play			
	Pause			
	Rec			
	<<			
	>>			
	PR+			
	PR-			
	1			
	2			
	3			
	4			
	5			
	6			
	7	