







Original	Sustituto
	Power
	Last
	Mute
	1
	2
	3
	4
	5
	6
	7
	8
	9
	0
	TV/R
	Audio
	Info
	Mode

Original	Sustituto
	Favor
	Menu
	Sub-T
	Exit
	Up
	Down
	Right
	Left
	Ok
	Ch +
	Ch -
	Vol +
	Vol -
	Red
	Green
	Yellow
	Blue





Original		Sustituto	
	EPG		Guide
	Text		Text

Original		Sustituto	





Original	Sustituto	Original	Sustituto
Power		Power	Power
Last		Pre Ch	Pre Ch
Mute		Mute	Mute
1		1	1
2		2	2
3		3	3
4		4	4
5		5	5
6		6	6
7		7	7
8		8	8
9		9	9
0		0	0
TV/R		TV/R	TV/R
Audio		Dual	Dual
Info		Info	Info
Mode		D. Menu	D. Menu

Original	Sustituto	Original	Sustituto
Favor		Options	Options
Menu		Menu	Menu
Sub-T		Subt	Subt
Exit		Exit	Exit
Up		Up	Up
Down		Down	Down
Right		Right	Right
Left		Left	Left
OK		Ok	Ok
CH+		Ch +	Ch +
CH-		Ch -	Ch -
Vol+		Vol +	Vol +
Vol-		Vol -	Vol -
Red		Red	Red
Green		Green	Green
Yellow		Yellow	Yellow
Blue		Blue	Blue





Original	Sustituto	Original	Sustituto
EPG	 Guide		
Text	 Text		





Original	Sustituto	
Power		Power
Last		Pre Ch
Mute		Mute
1		1
2		2
3		3
4		4
5		5
6		6
7		7
8		8
9		9
0		0
TV/R		TV/R
Audio		Dual
Info		Info
Mode		D. Menu

Original	Sustituto	
Favor		Options
Menu		Menu
Sub-T		Subt
Exit		Exit
Up		Up
Down		Down
Right		Right
Left		Left
OK		Ok
CH+		Ch +
CH-		Ch -
Vol+		Vol +
Vol-		Vol -
Red		Red
Green		Green
Yellow		Yellow
Blue		Blue



