







































































	Original	Sustituto		Original	Sustituto
	 Power	 Power		 Exit	 Exit
	 Mute	 Mute		 Up	 Up
	 1	 1		 Down	 Down
	 2	 2		 Right	 Right
	 3	 3		 Left	 Left
	 4	 4		 Ok	 Ok
	 5	 5		 Vol+	 Vol +
	 6	 6		 Vol-	 Vol -
	 7	 7		 Sound	 Shift + Dual
	 8	 8		 Pic	 Shift + Format
	 9	 9		 Ch+	 Ch +
	 0	 0		 Ch-	 Ch -
	 Audio	 Dual		 Sleep	 Sleep
	 Recall	 Back		 Aspect	 Format
	 Tv Menu	 Menu		 Freeze	 Eject
	 Source	 AV		 Tv/Radio	 TV/R
	 ChList	 List		 Text	 Text





Original	Sustituto
Epg	Guide
Fav	Pre Ch
Info	Info
Red	Red
Green	Green
Yellow	Yellow
Blue	Blue
Reveal	Media
Hold	D. Menu
Index	Shift + Info
Subpage	Shift + AV
List	Smart
Mix	Options
Subtitle	Subt
Size	3D
<<	<<
>>	>>

Original	Sustituto
I<<	I<<
>>I	>>I
Play	Play
Pause	Pause
Stop	Stop
Rec/Rep	Rec

