


































Original	Sustituto	Original	Sustituto
 Power Tv	 Power	 Back Tv	 Back
 Av Tv	 AV	 Ch+ Tv	 Ch +
 Menu Tv	 Menu	 Ch- Tv	 Ch -
 Up Tv	 Up	 P[≡] Tv	 I<<
 Down Tv	 Down	 P[ ] Tv	 >>I
 Left Tv	 Left	 << Tv	 <<
 Right Tv	 Right	 >> Tv	 >>
 Ok Tv	 Ok	 Stop Tv	 Stop
 Info Tv	 Info	 Play Tv	 Play
 Exit Tv	 Exit	 1 Tv	 1
 Red Tv	 Red	 2 Tv	 2
 Green Tv	 Green	 3 Tv	 3
 Yellow Tv	 Yellow	 4 Tv	 4
 Blue Tv	 Blue	 5 Tv	 5
 Vol+ Tv	 Vol +	 6 Tv	 6
 Vol- Tv	 Vol -	 7 Tv	 7
 Mute Tv	 Mute	 8 Tv	 8





Original	Sustituto
9 Tv	9
0 Tv	0
Text Tv	Text
#Help Tv	Pre Ch
▼P [=] Tv2	Shift + I<<
▲P [ ] Tv2	Shift + >>I
Rec Tv2	Shift + Rec
Play Tv2	Shift + Play
Av Tv2	Shift + AV
<< Tv2	Shift + <<
>> Tv2	Shift + >>
Power Tv2	Shift + Power
Guide Tv2	Shift + Guide
Menu Tv2	Shift + Menu
Up Tv2	Shift + Up
Left Tv2	Shift + Left
Right Tv2	Shift + Right

Original	Sustituto
Down Tv2	Shift + Down
Ok Tv2	Shift + Ok
Info Tv2	Shift + Info
Green Tv2	Shift + Green
Red Tv2	Shift + Red
Exit Tv2	Shift + Exit
Yellow Tv2	Shift + Yellow
Blue Tv2	Shift + Blue
Back Tv2	Shift + Back
Ch+ Tv2	Shift + Ch +
Ch- Tv2	Shift + Ch -
Stop Tv2	Shift + Stop
Pause Tv2	Shift + Pause
1 Tv2	Shift + 1
2 Tv2	Shift + 2
3 Tv2	Shift + 3
4 Tv2	Shift + 4











Original	Sustituto	Original	Sustituto
 Power DVD	 Power	 Mute DVD/DVR	 Mute
 AV DVD/DVR	 AV	 Back DVD/DVR	 Back
 Guide DVD/DVR	 Guide	 Ch+ DVD/DVR	 Ch +
 Menu DVD/DVR	 Menu	 vP[=] DVD/DVR	 I<<
 Info DVD/DVR	 Info	 Ch- DVD/DVR	 Ch -
 Exit DVD/DVR	 Exit	 AP[ ] DVD/DVR	 >>I
 Up DVD/DVR	 Up	 << DVD/DVR	 <<
 Down DVD/DVR	 Down	 >> DVD/DVR	 >>
 Left DVD/DVR	 Left	 Play DVD/DVR	 Play
 Right DVD/DVR	 Right	 Pause DVD/DVR	 Pause
 Ok DVD/DVR	 Ok	 Stop DVD/DVR	 Stop
 Red DVD/DVR	 Red	 Rec DVD/DVR	 Rec
 Green DVD/DVR	 Green	 1 DVD/DVR	 1
 Yellow	 Yellow	 2 DVD/DVR	 2
 Blue DVD/DVR	 Blue	 3 DVD/DVR	 3
 Vol+ DVD/DVR	 Vol +	 4 DVD/DVR	 4
 Vol- DVD/DVR	 Vol -	 5 DVD/DVR	 5










Original	Sustituto	Original	Sustituto
 Power	 Power	 Mute	 Mute
 Menu	 Menu	 Back	 Back
 Guide	 Guide	 Ch+ SAT/CABLE	 Ch +
 AV SAT/CABLE	 AV	 Ch- SAT/CABLE	 Ch -
 Up SAT/CABLE	 Up	 << SAT/CABLE	 <<
 Down	 Down	 >> SAT/CABLE	 >>
 Left SAT/CABLE	 Left	 Stop SAT/CABLE	 Stop
 Right	 Right	 Rec SAT/CABLE	 Rec
 Ok SAT/CABLE	 Ok	 Play SAT/CABLE	 Play
 Info SAT/CABLE	 Info	 Pause	 Pause
 Exit SAT/CABLE	 Exit	 1 SAT/CABLE	 1
 Red SAT/CABLE	 Red	 2 SAT/CABLE	 2
 Green	 Green	 3 SAT/CABLE	 3
 Yellow SAT/CABLE	 Yellow	 4 SAT/CABLE	 4
 Blue SAT/CABLE	 Blue	 5 SAT/CABLE	 5
 Vol+	 Vol +	 6 SAT/CABLE	 6
 Vol- SAT/CABLE	 Vol -	 7 SAT/CABLE	 7





Original		Sustituto	
	8 SAT/CABLE		8
	9 SAT/CABLE		9
	0 SAT/CABLE		0
	#Help		Pre Ch
	Text SAT/CABLE		Text

Original		Sustituto	





Original		Sustituto		Original		Sustituto	
	Power DVBT		Power		Ch+ DVBT		Ch +
	Guide DVBT		Guide		Ch- DVBT		Ch -
	Menu DVBT		Menu		Pause DVBT		Pause
	Up DVBT		Up		1 DVBT		1
	Down DVBT		Down		2 DVBT		2
	Left DVBT		Left		3 DVBT		3
	Right DVBT		Right		4 DVBT		4
	Ok DVBT		Ok		5 DVBT		5
	Info DVBT		Info		6 DVBT		6
	Red DVBT		Red		7 DVBT		7
	Green DVBT		Green		8 DVBT		8
	Yellow DVBT		Yellow		9 DVBT		9
	Blue DVBT		Blue		0 DVBT		0
	Vol+ DVBT		Vol +		Power VCR		Shift + Power
	Vol- DVBT		Vol -		Av VCR		AV
	Mute DVBT		Mute		<< VCR		<<
	Back DVBT		Back		Stop VCR		Stop







Original	Sustituto
>> VCR	>>
Play VCR	Play
Rec VCR	Rec
Pause VCR	Shift + Pause
Guide VCR	Shift + Guide
Menu VCR	Shift + Menu
Up VCR	Shift + Up
Down VCR	Shift + Down
Left VCR	Shift + Left
Right VCR	Shift + Right
Ok VCR	Shift + Ok
Info VCR	Shift + Info
Exit VCR	Exit
Red VCR	Shift + Red
Green VCR	Shift + Green
Yellow VCR	Shift + Yellow
Blue VCR	Shift + Blue

Original	Sustituto
Back VCR	Shift + Back
Ch+ VCR	Shift + Ch +
Ch-VCR	Shift + Ch -
1 VCR	Shift + 1
2 VCR	Shift + 2
3 VCR	Shift + 3
4 VCR	Shift + 4
5 VCR	Shift + 5
6 VCR	Shift + 6
7 VCR	Shift + 7
8 VCR	Shift + 8
9 VCR	Shift + 9
0 VCR	Shift + 0
Text VCR	Text
#Help VCR	Pre Ch

