






































































Original	Sustituto	Original	Sustituto
 Power	 Power	 Rec	 Rec
 Input D/A	 Smart	 I<<	 I<<
 Tv/Radio	 TV/R	 <<	 <<
 Input	 AV	 >>	 >>
 Bright-	 Shift + Left	 >>	 >>
 Bright+	 Shift + Right	 Menu	 Menu
 Simplink	 Media	 Back	 Back
 Text	 Text	 Exit	 Exit
 Ratio	 Format	 Info	 Info
 I-II	 Dual	 Guide	 Guide
 Red	 Red	 Up	 Up
 Green	 Green	 Down	 Down
 Yellow	 Yellow	 Right	 Right
 Blue	 Blue	 Left	 Left
 Stop	 Stop	 OK	 Ok
 Play	 Play	 FAV	 Pre Ch
 Pause	 Pause	 Vol+	 Vol +
















































Original	Sustituto
Vol-	Vol -
Mute	Mute
PR+	Ch +
PR-	Ch -
1	1
2	2
3	3
4	4
5	5
6	6
7	7
8	8
9	9
0	0
List	List
Q.View	Options
Update/[≡x]	Shift + Back

Original	Sustituto
Index/[≡i]	Shift + Info
Time/[≡o]	D. Menu
Sleep	Sleep
Hold/[≡+]	Eject
Reveal/[≡?]	3D
Subtitle	Subt









































Original		Sustituto		Original		Sustituto	
	Power		Power		4		4
	Stop		Stop		5		5
	Play		Play		6		6
	Pause		Pause		7		7
	I<<		I<<		8		8
	>>I		>>I		9		9
	<<		<<		0		0
	>>		>>				
	Menu		Menu				
	Up		Up				
	Down		Down				
	OK		Ok				
	Right		Right				
	Left		Left				
	1		1				
	2		2				
	3		3				







	Original	Sustituto	Original	Sustituto
	Power			8
	Input			9
	Stop			0
	Play			
	Pause			
	Rec			
	<<			
	>>			
	PR+			
	PR-			
	1			
	2			
	3			
	4			
	5			
	6			
	7	