







































































Original	Sustituto	Original	Sustituto
	Power		Power
	Source		SRC
	1		1
	2		2
	3		3
	4		4
	5		5
	6		6
	7		7
	8		8
	9		9
	0		0
	Guide		-/-- / EPG
	Infos		INFO
	Mute		MUTE
	Vol +		VOL +
	Vol -		VOL -
	Format		V-FOR
	Prog +		CH +
	Prog -		CH -
	Red		Red (A)
	Green		Green (B)
	Yellow		Yellow (C)
	Blue		Blue (D)
	Menu		MENU
	Media		MEDIA
	Up		UP
	Down		DOWN
	Right		RIGHT
	Left		LEFT
	OK		OK
	Back		BACK
	Exit		EXIT
	AD		Audio





Original	Sustituto
Subtitle	Subt.
Text	TEXT
Radio	TV/R
I<<	First
<<	Rewind
>>	Fast Forward
>>I	Last
Rec	Rec
Stop	Stop
Play	Play
Pause	Pause

Original	Sustituto

