







































































| Original | | Sustituto | | Original | | Sustituto | |
|---|--------|---|--------------------|---|--------|---|-----------------------------|
|  | Power |  | Power |  | Vol - |  | Vol- |
|  | Source |  | AV / Input / RDS |  | Format |  | Picture / Format |
|  | 1 |  | 1 |  | Prog - |  | CH- / Page- |
|  | 2 |  | 2 |  | Red |  | Red / Netflix / Search |
|  | 3 |  | 3 |  | Green |  | Green / APP / Repeat |
|  | 4 |  | 4 |  | Yellow |  | Yellow / YouTube / Repeat |
|  | 5 |  | 5 |  | Blue |  | Blue / Prime Video / Random |
|  | 6 |  | 6 |  | Menu |  | Menu / Home |
|  | 7 |  | 7 |  | Media |  | Display / Media |
|  | 8 |  | 8 |  | Up |  | Up |
|  | 9 |  | 9 |  | Left |  | Left |
|  | Guide |  | Guide / EPG / -/-- |  | OK |  | OK |
|  | 0 |  | 0 |  | Right |  | Right |
|  | Infos |  | Info / Angle |  | Back |  | Back / Return |
|  | Vol + |  | Vol+ |  | Back |  | Shift + Back / Return |
|  | Mute |  | Mute / Dimmer |  | Down |  | Down |
|  | Prog + |  | CH+ / Page+ |  | Exit |  | Exit / Cancel / Clear |





| Original | | Sustituto | |
|---|----------|---|-----------------------|
|  | AD |  | Audio / Lang I/II |
|  | Subtitle |  | Subtitle / EQ |
|  | Text |  | Text / Goto |
|  | Radio |  | TV/Radio / |
|  | I<< |  | I<< / Preset- |
|  | << |  | << / Tune- |
|  | >> |  | >> / Tune+ |
|  | >>I |  | >>I / Preset+ |
|  | Rec |  | Rec / Rec Mode |
|  | Stop |  | Stop / Hold |
|  | Play |  | Play / Slow |
|  | Pause |  | Pause / Step / Freeze |
| | | | |
| | | | |
| | | | |
| | | | |

| Original | | Sustituto | |
|----------|--|-----------|--|
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |

