



Original	Sustituto	Original	Sustituto
	Power		Power
	Open/Close		Eject
	DVD		Red
	Tuner		Green
	Video		Yellow
	TV/AUX		Blue
	Sleep		Sleep
	I<<		I<<
	<<		<<
	>>		>>
	>>I		>>I
	Play		Play
	Stop		Stop
	SP.Setup		Media
	CH-Level		Guide
	SR.Mode		List
	Title		Info
	Up		Up
	Down		Down
	Right		Right
	Left		Left
	Enter		Ok
	Vol+		Vol +
	Vol-		Vol -
	Mute		Mute
	Setup		Options
	Pause/Step		Pause
	Menu/Return		Menu
	Goto Auto		Back
	1		1
	2		2
	3		3
	4		4
	5		5



