







































































Original	Sustituto
 Power	 Power
 Mute	 Mute
 1	 1
 2	 2
 3	 3
 4	 4
 5	 5
 6	 6
 7	 7
 8	 8
 9	 9
 0	 0
 (i)	 Info
 AV	 AV
 Red	 Red
 Green	 Green
 Yellow	 Yellow

Original	Sustituto
 Blue	 Blue
 TV	 TV/R
 Menu	 Menu
 [≡]/Top Menu	 Text
 Back	 Back
 P+	 Ch +
 P-	 Ch -
 Vol+	 Vol +
 Vol-	 Vol -
 Up	 Up
 Down	 Down
 Right	 Right
 Left	 Left
 OK	 Ok
 ↑/[+]	 Pre Ch
 F.T/L	 Options
 [?]	 3D





	Original	Sustituto	Original	Sustituto
		Power		Power
		(i)		Info
		Menu		Menu
		Up		Up
		Down		Down
		Right		Right
		Left		Left
		OK		Ok
		Top Menu	+	Shift + Menu
		Back		Back
		↑/[+]		Pre Ch
		↓/[]		Guide
		<<		<<
		Play		Play
		>>		>>
		Stop		Stop
		Pause		Pause



