




































Original	Sustituto
 Power	 Power
 Mute	 Mute
 Text	 Text
 Subtitle	 Subt
 List	 List
 1	 1
 2	 2
 3	 3
 4	 4
 5	 5
 6	 6
 7	 7
 8	 8
 9	 9
 0	 0
 Recall	 3D
	 Back

Original	Sustituto
 Menu	 Menu
 Source	 AV
 Exit	 Exit
 Info	 Info
 Up	 Up
 Down	 Down
 Right/Zoom+	 Right
 Left/Zoom-	 Left
 OK	 Ok
 Smart Tv	 Smart
 YouTube	 Media
 Netflix	 Shift + Media
 CH+	 Ch +
 CH-	 Ch -
 Vol+	 Vol +
 Vol-	 Vol -
 Red	 Red





Original	Sustituto	Original	Sustituto
 Green	 Green		
 Yellow	 Yellow		
 Blue/O)/Lang	 Blue		
 P.Mode	 Format		
 S.Mode	 Dual		
 Sleep	 Sleep		
 Guide	 Guide		
 FAV	 Pre Ch		
 Option	 Options		
 <<	 <<		
 >>	 >>		
 I<	 I<<		
 Play	 Play		
 Pause	 Pause		
 Stop	 Stop		
 >I	 >>I		

