



Original	Sustituto
Power	Power
Open/Close	Eject
1	1
2	2
3	3
4	4
5	5
6	6
7	7
8	8
9	9
0	0
Mirroring	Guide
Setting	Shift + Options
Netflix	Media
Home	Smart
Internet	Shift + Smart

Original	Sustituto
Pop-Up Menu	D. Menu
Top Menu	Menu
Option	Options
Return	Back
Up	Up
Down	Down
Right/ >	Right
< /Left	Left
OK	Ok
Red	Red
Green	Green
Yellow	Yellow
Blue	Blue
<<	<<
Play	Play
>>	>>
<<	<<





Original		Sustituto	
	Pause		Pause
	>>I		>>I
	Stop		Stop
	Manual Skip +60s	+	Shift + Right
	Manual Skip -10s	+	Shift + Left
	Status		TV/R
	Playback Info		Info
	Subtitle		Subt
	Audio		Dual
	Picture Setting		Format
	HDR Setting		3D
	Sound Effect	+	Shift + Dual
	High Clarity		Text
	DIM		List
	Power Tv	+	Shift + Power
	AV Input Tv		AV
	Vol+ Tv		Vol +

Original		Sustituto	
	Vol- Tv		Vol -
	CH+ Tv		Ch +
	CH- Tv		Ch -

