



Original	Sustituto
Standby	Power
Mute	Mute
1	1
2	2
3	3
4	4
5	5
6	6
7	7
8	8
9	9
0	0
Display	Info
Recall	Back
Setup	Menu
EPG	Guide
Source	AV

Original	Sustituto
Audio	Dual
Subtitle	Subt
CH.List	List
FAV	Pre Ch
Up	Up
Down	Down
Right	Right
Left	Left
Ok	Ok
Vol+	Vol +
Vol-	Vol -
Exit/Cancel	Exit
S.Mode	Shift + Dual
P.Mode	Format
CH+/Page+	Ch +
CH-/Page-	Ch -
Red/Goto	Red





Original	Sustituto	Original	Sustituto
 Green/A-B	 Green	 Zoom+/Size	 Shift + Ch +
 Yellow/Repeat	 Yellow	 Zoom-	 Shift + Ch -
 Blue/Angle	 Blue	 Eject	 Eject
 Record	 Rec	 Sleep	 Sleep
 Rec. List	 Smart		
 TV/Radio	 TV/R		
 Scaler	 3D		
 Play	 Play		
 Pause/Reveal	 Pause		
 Stop/Index	 Stop		
 I<< Mix	 I<<		
 <</Mix	 <<		
 >> Text	 >>		
 >> Text	 >>		
 Text	 Text		
 S. Page /	 D. Menu		
 Hold/Title	 Media		

