

























































Original	Sustituto
 Power	 Power
 Tv	 TV/R
 1	 1
 2	 2
 3	 3
 4	 4
 5	 5
 6	 6
 7	 7
 8	 8
 9	 9
 0	 0
 Enter	 Ok
 PRE-CH	 Pre Ch
 CH LIST	 List
 FAV CH	 Shift + Pre Ch
 Tools	 Options

Original	Sustituto
 Menu	 Menu
 Return	 Back
 Info	 Info
 Exit	 Exit
 Up	 Up
 Down	 Down
 Right	 Right
 Left	 Left
 Enter	 Eject
 Red	 Red
 Green	 Green
 Yellow	 Yellow
 Blue	 Blue
 Vol+	 Vol +
 Vol-	 Vol -
 Mute	 Mute
 Source	 AV





Original	Sustituto	Original	Sustituto
	PR+		Ch +
	PR-		Ch -
	TTX/MIX		Text
	Media.P		Media
	P.Size		Format
	Dual		Dual
	Guide		Guide
	Subt		Subt
	<<		<<
	Pause		Pause
	>>		>>
	Rec		Rec
	Play		Play
	Stop		Stop

